

Replacement Element "X" Dimension Calculations

ASSEMBLY TYPE	REPLACEMENT ELEMENT "X" DIMENSION
SL	Assembly "X" length - 1/4 inch
PC	Assembly "X" length + "E" length + 1/2 inch
LE	Same as assembly "X" length

Standard Vibration Spacer Placement

ASSEMBLY LENGTH	SPACER SPECIFICATIONS
4 inches to 18 inches	2 spacers equally spaced
> 18 inches to 36 inches	3 spacers equally spaced
> 36 inches	1 additional spacer for each additional 18 inches. All spacers are equally spaced.

🚺 pyromalion's ·

Μ

8VS50

8VS75

Special limits of error

316 Stainless steel vibration spacers

for 1/2 inch schedule 40 pipe 316 Stainless steel vibration spacers

for 3/4 inch schedule 40 pipe