


NivoGuide 8100, 3100, 8200

Two-wire 4 ... 20 mA/HART

With SIL qualification



Safety Manual



Document ID: 63542



Contents

| | |
|---|-----------|
| 1 Document language | 3 |
| 2 Scope | 4 |
| 2.1 Instrument version | 4 |
| 2.2 Application area | 4 |
| 2.3 SIL conformity | 4 |
| 3 Planning | 5 |
| 3.1 Safety function | 5 |
| 3.2 Safe state | 5 |
| 3.3 Prerequisites for operation | 5 |
| 4 Safety-related characteristics..... | 6 |
| 4.1 Characteristics acc. to IEC 61508 | 6 |
| 4.2 Characteristics acc. to ISO 13849-1 | 6 |
| 4.3 Supplementary information | 7 |
| 5 Setup | 9 |
| 5.1 General information..... | 9 |
| 5.2 Instrument parameter adjustment..... | 9 |
| 6 Diagnostics and servicing | 11 |
| 6.1 Behaviour in case of failure | 11 |
| 6.2 Repair | 11 |
| 7 Proof test | 12 |
| 7.1 General information..... | 12 |
| 7.2 Test 1: Without checking the process variable | 12 |
| 7.3 Test 2: With check of the process variable..... | 13 |
| 8 Appendix A: Test report | 14 |
| 9 Appendix B: Term definitions..... | 15 |
| 10 Supplement C: SIL conformity..... | 16 |

1 Document language

| | |
|----|--|
| DE | Das vorliegende <i>Safety Manual</i> für Funktionale Sicherheit ist verfügbar in den Sprachen Deutsch, Englisch, Französisch und Russisch. |
| EN | The current <i>Safety Manual</i> for Functional Safety is available in German, English, French and Russian language. |
| FR | Le présent <i>Safety Manual</i> de sécurité fonctionnelle est disponible dans les langues suivantes: allemand, anglais, français et russe. |
| RU | Данное руководство по функциональной безопасности <i>Safety Manual</i> имеется на немецком, английском, французском и русском языках. |

2 Scope

2.1 Instrument version

This safety manual applies to TDR sensors

NivoGuide 8100, 3100, 8200

Electronics types:

- Two-wire 4 ... 20 mA/HART with SIL qualification
- Two-wire 4 ... 20 mA/HART with SIL qualification and supplementary electronics "Additional current output 4 ... 20 mA"

Valid versions:

- from HW Ver 1.0.0
- from SW Ver 1.0.0

Probe types:

- Only original probes of the manufacturer must be used!

2.2 Application area

The transmitter can be used in a safety-related system according to IEC 61508 in the modes *low demand mode* or *high demand mode* for the measurement of the following process variables:

- Point level detection
- Level measurement in liquids and bulk solids
- Interface measurement in liquids

Due to the systematic capability SC3 this is possible up to:

- SIL2 in single-channel architecture
- SIL3 in multiple channel architecture

The following interface can be used to output the measured value:

- Current output: 4 ... 20 mA

SIL The following interfaces are only permitted for parameter adjustment and for informative use:

- HART®
- Display and adjustment module
- USB Communicator
- Current output II ¹⁾

2.3 SIL conformity

The SIL conformity was independently judged and certified by the *TÜV Rheinland* according to IEC 61508:2010 (Ed.2). ²⁾

SIL The certificate is valid for the entire service life of all instruments that were sold before the certificate expired!

¹⁾ Only with instrument version with supplementary electronics "Additional current output 4 ... 20 mA".

²⁾ Verification documents see appendix

3 Planning

3.1 Safety function

Safety function

The transmitter generates on its current output a signal between 3.8 mA and 20.5 mA corresponding to the process variable. This analogue signal is fed to a connected processing system to monitor the following conditions:

- Exceeding a defined limit value of the process variable
- Falling below a defined limit value of the process variable
- Monitoring of a defined range of the process variable

Safety tolerance

For the design of the safety function, the following aspects must be taken into account with regard to the tolerances:

- Due to undetected failures in the range between 3.8 mA and 20.5 mA, an incorrect output signal can be generated which deviates from the real measured value by up to 2 %
- Increased measurement deviations can occur at the boundaries of the measuring range (see Technical Data in the operating instructions)

3.2 Safe state

Safe state

The safe state of the current output depends on the safety function and the characteristics set on the sensor.

| Characteristics | Monitoring upper limit value | Monitoring lower limit value |
|-----------------|---------------------------------------|---------------------------------------|
| 4 ... 20 mA | Output current \geq Switching point | Output current \leq Switching point |
| 20 ... 4 mA | Output current \leq Switching point | Output current \geq Switching point |

Fault signals in case of malfunction

Possible fault currents:

- ≤ 3.6 mA ("fail low")
- > 21 mA ("fail high")

3.3 Prerequisites for operation

Instructions and restrictions

- The measuring system should be used appropriately taking pressure, temperature, density and chemical properties of the medium into account. The application-specific limits must be observed.
- The specifications according to the operating instructions manual, particularly the current load on the output circuits, must be kept within the specified limits
- Existing communication interfaces (e. g. HART, USB) are not used for transmission of the safety-relevant measured value
- The instructions in chapter " *Safety-related characteristics* ", paragraph " *Supplementary information* " must be noted
- All parts of the measuring chain must correspond to the planned " *Safety Integrity Level (SIL)* "

4 Safety-related characteristics

4.1 Characteristics acc. to IEC 61508

| Parameter | Value |
|--|--|
| Safety Integrity Level | SIL2 in single-channel architecture SIL3 in multiple channel architecture ³⁾ |
| Hardware fault tolerance | HFT = 0 |
| Instrument type | Type B |
| Mode | Low demand mode, High demand mode |
| SFF | > 90 % |
| MTTR | 8 h |
| MTBF = MTTF + MTTR ⁴⁾ | 0.3 x 10 ⁶ h (35 years) |
| Diagnostic test interval ⁵⁾ | < 30 min |

Failure rates

| λ_s | λ_{DD} | λ_{DU} | λ_H | λ_L | λ_{AD} |
|-------------|----------------|----------------|-------------|-------------|----------------|
| 0 FIT | 2154 FIT | 158 FIT | 9 FIT | 60 FIT | 32 FIT |

| | | |
|--------------------|------------------------------|----------------|
| PFD _{AVG} | 0.133 x 10 ⁻² | (T1 = 1 year) |
| PFD _{AVG} | 0.196 x 10 ⁻² | (T1 = 2 years) |
| PFD _{AVG} | 0.382 x 10 ⁻² | (T1 = 5 years) |
| PFH | 0.158 x 10 ⁻⁶ 1/h | |

Proof Test Coverag (PTC)

| Test type ⁶⁾ | Remaining failure rate of dangerous undetected failures | PTC |
|-------------------------|---|------|
| Test 1 | 11 FIT | 93 % |
| Test 2 | 4 FIT | 98 % |

4.2 Characteristics acc. to ISO 13849-1

The transmitter has been manufactured and verified using principles that demonstrate its suitability and reliability for safety-related applications. It can therefore be considered a "proven component" according to DIN EN ISO 13849-1.

Derived from the safety-related characteristics, the following figures result according to ISO 13849-1 (safety of machinery): ⁷⁾

| Parameter | Value |
|-----------|----------|
| MTTFd | 47 years |

³⁾ Homogeneous redundancy possible, because systematic capability SC3.

⁴⁾ Including errors outside the safety function.

⁵⁾ Time during which all internal diagnoses are carried out at least once.

⁶⁾ See section "Proof test".

⁷⁾ ISO 13849-1 was not part of the certification of the instrument.

| Parameter | Value |
|-------------------|---------------------------|
| DC | 93 % |
| Performance Level | 1.58×10^{-7} 1/h |

4.3 Supplementary information

Determination of the failure rates

The failure rates of the instruments were determined by an FMEDA according to IEC 61508. The calculations are based on failure rates of the components according to **SN 29500**:

All figures refer to an average ambient temperature of 40 °C (104 °F) during the operating time. For higher temperatures, the values should be corrected:

- Continuous application temperature > 50 °C (122 °F) by factor 1.3
- Continuous application temperature > 60 °C (140 °F) by factor 2.5

Similar factors apply if frequent temperature fluctuations are expected.

Assumptions of the FMEDA

- The failure rates are constant. Take note of the useful service life of the components according to IEC 61508-2.
- Multiple failures are not taken into account
- Wear on mechanical parts is not taken into account
- Failure rates of external power supplies are not taken into account
- The environmental conditions correspond to an average industrial environment

Calculation of PFD_{AVG}

The values for PFD_{AVG} specified above were calculated as follows for a 1oo1 architecture:

$$PFD_{AVG} = \frac{PTC \times \lambda_{DU} \times T1}{2} + \lambda_{DD} \times MTTR + \frac{(1 - PTC) \times \lambda_{DU} \times LT}{2}$$

Parameters used:

- T1 = Proof Test Interval
- PTC = 90 %
- LT = 10 years
- MTTR = 8 h

Boundary conditions relating to the configuration of the processing unit

A connected control and processing unit must have the following properties:

- The failure signals of the measuring system are judged according to the idle current principle
- "fail low" and "fail high" signals are interpreted as a failure, whereupon the safe state must be taken on

If this is not the case, the respective percentages of the failure rates must be assigned to the dangerous failures and the values stated in chapter *Safety-related characteristics* redetermined!

Multiple channel architecture

Due to the systematic capability SC3, this instrument can also be used in multiple channel systems up to SIL3, also with a homogeneously redundant configuration.

4 Safety-related characteristics

The safety-related characteristics must be calculated especially for the selected structure of the measuring chain using the stated failure rates. In doing this, a suitable Common Cause Factor (CCF) must be considered (see IEC 61508-6, appendix D).

5 Setup

5.1 General information

Mounting and installation Take note of the mounting and installation instructions in the operating instructions manual.

Setup must be carried out under process conditions.

Function test



When locking the adjustment, the instrument checks the data of the measurement loop and decides on the basis of the evaluation results if it is necessary to check the level.

Hence the following actions must be carried out at the time of every startup:

- Unlock adjustment
- If necessary, change parameters
- Lock adjustment and verify modified parameters, if necessary

5.2 Instrument parameter adjustment

Tools

The following adjustment units are permitted for parameterization of the safety function:

- Display and adjustment module
- The DTM suitable for NivoGuide 8100, 3100, 8200 in conjunction with an adjustment software according to the FDT/DTM standard, e. g. PACTware
- The device description EDD suitable for NivoGuide 8100, 3100, 8200

The parameter adjustment is described in the operating instructions manual.



Wireless connection is also possible with existing Bluetooth function.



The documentation of the device settings is only possible with the full version of the DTM Collection.

Safety-relevant parameters

For protection against unwanted or unauthorized adjustment, the set parameters must be protected against unauthorized access. For this reason, the instrument is shipped in locked condition. The PIN in delivery status is "0000".

The default values of the parameters are listed in the operating instructions. When shipped with customer-specific parameter settings, the instrument is accompanied by a list of the values differing from the default values.

Safe parameterization

To avoid or detect possible errors during parameter adjustment for unsafe operating environments, a verification procedure is used that allows the safety-relevant parameters to be checked.

Parameter adjustment proceeds according to the following steps:

- Unlock adjustment
- Change parameters
- Lock adjustment and verify modified parameters

The exact process is described in the operating instructions.



The instrument is shipped in locked condition!



For verification, all modified, safety-relevant and non safety-relevant parameters are shown.

The verification texts are displayed either in German or, when any other menu language is used, in English.

Unsafe device status



Warning:

When adjustment is unlocked, the safety function must be considered as unreliable. This applies until the parameters are verified and the adjustment is locked again. If the parameter adjustment process is not carried out completely, the device statuses described in the operating instructions must be taken into consideration.

If necessary, you must take other measures to maintain the safety function.

Instrument reset



Warning:

In case a reset to "*Delivery status*" or "*Basic setting*" is carried out, all safety-relevant parameters must be checked or set anew.

6 Diagnostics and servicing

6.1 Behaviour in case of failure

Internal diagnosis

The instrument permanently monitored by an internal diagnostic system. If a malfunction is detected, a fault signal will be output on the safety-relevant output (see section " *Safe status*").

The diagnosis interval is specified in chapter " *Safety-related characteristics*".

Error messages in case of malfunction

A fault message coded according to the type of fault is output. The fault messages are listed in the operating instructions.



If failures are detected, the entire measuring system must be shut down and the process held in a safe state by other measures.

The manufacturer must be informed of the occurrence of a dangerous undetected failure (incl. fault description).

6.2 Repair

Electronics exchange

The procedure is described in the operating instructions manual. Note the instructions for parameter adjustment and setup.

Software update

The procedure is described in the operating instructions manual. Note the instructions for parameter adjustment and setup.

7 Proof test

7.1 General information

Objective

To identify possible dangerous, undetected failures, the safety function must be checked by a proof test at adequate intervals. It is the user's responsibility to choose the type of testing. The time intervals are determined by the selected PFD_{AVG} (see chapter "Safety-related characteristics").

For documentation of these tests, the test protocol in the appendix can be used.

If one of the tests proves negative, the entire measuring system must be switched out of service and the process held in a safe state by means of other measures.

In a multiple channel architecture this applies separately to each channel.

Preparation

- Determine safety function (mode, switching points)
- If necessary, remove the instruments from the safety chain and maintain the safety function by other means
- Provide an approved adjustment unit

Unsafe device status



Warning:

During the function test, the safety function must be treated as unreliable. Take into account that the function test influences downstream connected devices.

If necessary, you must take other measures to maintain the safety function.

After the function test, the status specified for the safety function must be restored.

7.2 Test 1: Without checking the process variable

Conditions

- Instrument can remain in installed condition
- Output signal corresponds to the assigned process variable
- Device status in the menu Diagnosis: "OK"

Distance from the sensor reference point to the level

- > 300 mm with NG****.***B****.***** without reference distance

Procedure

1. Carry out a re-start (separate the test item at least 10 seconds from mains voltage)
2. Press the menu item "Start proof test" in the menu Diagnosis on the adjustment unit

Expected result

Step 1: Output signal corresponds to the assigned process variable and the device status in the menu Diagnosis is "OK"

Step 2: Adjustment unit signals "Test successful"

Proof Test Coverage

See *Safety-related characteristics*

7.3 Test 2: With check of the process variable

Conditions

- Instrument can remain in installed condition
- Output signal corresponds to the assigned process variable
- Device status in the menu Diagnosis: "OK"

Distance from the sensor reference point to the level

- > 300 mm with NG****.***B**** ***** without reference distance

Procedure

1. Carry out a re-start (separate the test item at least 10 seconds from mains voltage)
2. Carry out the function test according to the operating instructions just like during initial operation.

Expected result

Step 1: Output signal corresponds to the assigned process variable and the device status in the menu Diagnosis is "OK"

Step 2: Successful function test

Proof Test Coverage

See *Safety-related characteristics*

8 Appendix A: Test report

| Identification | |
|-----------------------------|--|
| Company/Tester | |
| Plant/Instrument TAG | |
| Meas. loop TAG | |
| Instrument type/Order code | |
| Instrument serial number | |
| Date, setup | |
| Date of the last proof test | |

| Test reason/Test scope | |
|-------------------------------|--|
| | Setup without checking the process variable |
| | Setup with check of the process variable |
| | Proof test without checking the process variable |
| | Proof test with check of the process variable |

| Mode | |
|-------------|------------------------------------|
| | Monitoring of an upper limit value |
| | Monitoring a lower limit value |
| | Range monitoring |

| Adjusted parameters of the safety function are documented | |
|--|-----|
| | Yes |
| | No |

| Test result (if necessary) | | | | |
|-----------------------------------|--------------------------------|-------------------------|------------|-------------|
| Test point | Process variable ⁸⁾ | Expected measured value | Real value | Test result |
| Value 1 | | | | |
| Value 2 | | | | |
| Value 3 | | | | |
| Value 4 | | | | |
| Value 5 | | | | |

| Confirmation | |
|---------------------|------------|
| Date: | Signature: |

⁸⁾ e.g.: limit level, level, interface, pressure, flow, density

9 Appendix B: Term definitions

Abbreviations

| | |
|----------------|---|
| SIL | Safety Integrity Level (SIL1, SIL2, SIL3, SIL4) |
| SC | Systematic Capability (SC1, SC2, SC3, SC4) |
| HFT | Hardware Fault Tolerance |
| SFF | Safe Failure Fraction |
| PFD_{AVG} | Average Probability of dangerous Failure on Demand |
| PFH | Average frequency of a dangerous failure per hour (Ed.2) |
| FMEDA | Failure Mode, Effects and Diagnostics Analysis |
| FIT | Failure In Time (1 FIT = 1 failure/10 ⁹ h) |
| λ_{SD} | Rate for safe detected failure |
| λ_{SU} | Rate for safe undetected failure |
| λ_S | $\lambda_S = \lambda_{SD} + \lambda_{SU}$ |
| λ_{DD} | Rate for dangerous detected failure |
| λ_{DU} | Rate for dangerous undetected failure |
| λ_H | Rate for failure, who causes a high output current (> 21 mA) |
| λ_L | Rate for failure, who causes a low output current (≤ 3.6 mA) |
| λ_{AD} | Rate for diagnostic failure (detected) |
| λ_{AU} | Rate for diagnostic failure (undetected) |
| DC | Diagnostic Coverage |
| PTC | Proof Test Coverage (Diagnostic coverage for manual proof tests) |
| T1 | Proof Test Interval |
| LT | Useful Life Time |
| MTBF | Mean Time Between Failure = MTTF + MTTR |
| MTTF | Mean Time To Failure |
| MTTR | IEC 61508, Ed1: Mean Time To Repair IEC 61508, Ed2: Mean Time To Restoration |
| $MTTF_d$ | Mean Time To dangerous Failure (ISO 13849-1) |
| PL | Performance Level (ISO 13849-1) |

10 Supplement C: SIL conformity

SIL Manufacturer declaration, NE130: Form B.1

| Manufacturer | |
|---|--|
| UWT GmbH Westendstraße 5 87488 Betzigau | |

| General | | | |
|--|--|--|-------------|
| Device designation and permissible types | NivoGuide 8100, 3100, 8200 | | |
| Safety-related output signal | 4...20mA/HART - two-wire with SIL qualification | Item-No: NG****.***B**** ***** | |
| Fault current | ≥ 21 mA; ≤ 3,6 mA | | |
| Process variable / function | TDR sensor for level and interface measurement | | |
| Safety function(s) | Generation of a measured value to monitor MIN / MAX / Range | | |
| Device type acc. to IEC 61508-2 | <input type="checkbox"/> Type A | <input checked="" type="checkbox"/> Type B | |
| Operating mode | <input checked="" type="checkbox"/> Low Demand Mode | <input checked="" type="checkbox"/> High Demand or Continuous Mode | |
| Valid Hardware-Version | ≥ 1.0.0 | | |
| Valid Software-Version | ≥ 1.0.0 | | |
| Safety manual | Document ID: 63542 | | |
| Type of evaluation (check only one box) | <input checked="" type="checkbox"/> Complete HW/SW evaluation parallel to development incl. FMEDA and change request acc. to IEC 61508-2, 3 <input type="checkbox"/> Evaluation of "Prior use" performance for HW/SW incl. FMEDA and change request acc. to IEC 61508-2, 3 <input type="checkbox"/> Evaluation of HW/SW field data to verify „prior use“ acc. to IEC 61511 <input type="checkbox"/> Evaluation by FMEDA acc. to IEC61508-2 for devices without software | | |
| Evaluation through (incl. certificate no.) | TÜV Rheinland Industry Service GmbH, Nr./No. 968/FSP 2098.00/20 | | |
| Test documents | Development documents | Test reports | Data sheets |

| Safety Integrity | | | |
|----------------------------|----------------------------|--|--|
| Systematic Capability (SC) | | <input type="checkbox"/> SC2 for SIL2 | <input checked="" type="checkbox"/> SC3 for SIL3 |
| Hardware Safety Integrity | Single-channel use (HFT=0) | <input checked="" type="checkbox"/> SIL2 capable | <input type="checkbox"/> SIL3 capable |
| | Multi-channel use (HFT≥1) | <input type="checkbox"/> SIL2 capable | <input checked="" type="checkbox"/> SIL3 capable |

| FMEDA | |
|---|---|
| Safety function(s) | MIN / MAX / Range |
| λ _{DU} (FIT = Failure In Time / 10 ⁹ h) | 158 FIT |
| λ _{DD} | 2255 FIT |
| λ _{SU} | 0 FIT |
| λ _{SD} | 0 FIT |
| SFF (Safe Failure Fraction) | > 90 % |
| PTC (Proof Test Coverage) | Test 1: 93 % Test 2: 98 %, with checking the level |
| FMEDA data source | SN 29500 |

| Declaration | |
|-------------------------------------|--|
| <input checked="" type="checkbox"/> | Our internal company quality management system ensures information on safety-related systematic faults which become evident in the future. |

Certificate



No.: 968/FSP 2098.00/20

| | | | |
|-----------------------|---|---------------------------|--|
| Product tested | Sensors for level detection, level and interface measurement NIVOGUIDE | Certificate holder | UWT GmbH Westendstraße 5 87448 Betzigau Germany |
|-----------------------|---|---------------------------|--|

Type designation NIVOGUIDE 8100, NIVOGUIDE 3100, NIVOGUIDE 8200

| | | |
|----------------------------|---|---|
| Codes and standards | IEC 61508 Parts 1-7:2010 IEC 61511-1:2016+ Corr.1:2016 + AMD1:2017 IEC 61326-3-2:2017 | EN 12952-11:2007 (in extracts) EN 12953-9:2007 (in extracts) |
|----------------------------|---|---|

Intended application Sensors for level detection and level measurement of liquids and bulk solids as well as for interface measurement of liquids. The TDR-sensors of the NIVOGUIDE series comply with the requirements of the stated standards and can be used in a safety-related system acc. IEC 61508 up to SIL 2 and redundant (HFT=1) up to SIL 3 (Systematic Capability SC 3).
The type NIVOGUIDE 8200 is also suitable for the use as water level limiter according to EN 12952-11 and EN 12953-9 in steam vessel systems.
For more details see annex to the certificate.

Specific requirements The instructions of the associated Installation, Operating and Safety Manual shall be considered.

Valid until 2025-04-24

The issue of this certificate is based upon an examination, whose results are documented in Report No. 968/FSP 2098.00/20 dated 2020-07-29.
This certificate is valid only for products which are identical with the product tested.

TÜV Rheinland Industrie Service GmbH
Bereich Automation
Funktionale Sicherheit
Am Grauen Stein, 51105 Köln

Köln, 2020-07-29

Certification Body Safety & Security for Automation & Grid

Dipl.-Ing. Gebhard Bouwer

www.fs-products.com
www.tuv.com

TÜVRheinland®
Precisely Right.

TÜV Rheinland Industrie Service GmbH, Am Grauen Stein, 51105 Köln / Germany
Tel.: +49 221 806-1700, Fax: +49 221 806-1555, E-Mail: industrie-service@tuw.tuv.com

10222.12.12 E.A. © TÜV, TÜV and TUV are registered trademarks. Utilisation and application requires prior approval.

Printing date:

All statements concerning scope of delivery, application, practical use and operating conditions of the sensors and processing systems correspond to the information available at the time of printing.
Subject to change without prior notice

Technical support

Please contact your local sales partner (address at www.uwt.de). Otherwise please contact us:

UWT GmbH
Westendstraße 5
87488 Betzigau
Germany

Phone +49 831 57123-0
Fax +49 831 76879
info@uwt.de
www.uwt.de

63542-EN-200826