ConsoliDator+ Input/Output Card Assembly Instructions

The input/output card assembly instructions apply to the following cards: PDA9000-C4AI (Isolated 4-20 mA Input Card), PDA9000-C4PI (Pulse Inputs Card), PDA9000-C5AO (Isolated 4-20 mA Outputs Card), PDA9000-C5RY (Relays Card)



Hazardous voltages exist within enclosure. Only trained service personnel should perform installation and service.

Disconnect power and signal from the controller prior to performing the upgrade procedure below.



To Prevent damage to electronic components caused by electrostatic discharge, a grounding strap should be worn when performing the upgrade procedure below.

Step Description Illustrations (a-b) Remove the terminal connector b plugs and back cover: a. Before removing the back cover of the electronics, remove any existing terminal connector plugs. b. Remove the back cover of the electronics by unscrewing the (8) screws using a Phillips screwdriver. See red arrows for screw locations. b Install the option card: a. Locate an empty card slot where you want to install the card. See red arrows for card slot locations. 2 **b.** Slide the card into the card rails on each side of the slot and then push it down to connect it to the pins at the bottom. Apply the label sticker: a b **a.** Before placing the electronics cover back on the unit, remove the slot cover from the location where the new card has been installed, by popping it out using a flat head screwdriver. b. Then apply a label sticker around the open slot. See red outline for location of sticker.



Place the electronics cover back on the unit and fasten the (8) screws, then plug back in all the existing terminal connector plugs into the appropriate connectors.

