# PD688 & PD689 FM APPROVED, CSA CERTIFIED, & ATEX CERTIFIED Intrinsic Loop-powered Meter Safety Barrier Connections


SECTION	<b>AGENCY</b>	DESCRIPTION
1.0		General Notes
2.0	FM	Single or Dual Channel Intrinsic Safety Barrier
3.0	CSA	Single or Dual Channel Intrinsic Safety Barrier-Entity Installation
4.0	ATEX	Single or Dual Channel Intrinsic Safety Barrier

NOTE: THIS IS AN AGENCY CONTROLLED DOCUMENT NO CHANGES CAN BE MADE WITHOUT PRIOR APPROVAL.

#### 1.0 GENERAL NOTES

- 1.1 Control room equipment must not use or generate more than 250 VRMS or VDC.
- 1.2 US installations must be in accordance with ANSI/ISA RP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous (Classified) Locations" and the National Electrical Code (ANSI/NFPA 70). Canadian installations must be in accordance with the Canadian Electrical Code, Part 1. European Community installations must be in accordance with ATEX directive 94/9/EC.
- 1.3 Dust-tight conduit seals must be used when installed in Class II and Class III environments.
- 1.4 Hazardous location installation instructions for associated apparatus (barrier) must also be followed when installing this equipment.
- 1.5 For safe installation of an FM Approved/CSA Certified/ATEX Certified transmitter in series with PD688/PD689 loop indicator, the hazardous location installation instructions for the transmitter, PD688/PD689 loop indicator, and associated apparatus (barrier) must be compatible.
- **1.6** PD688/PD689 indicator does not add capacitance or inductance to loop under normal or fault conditions.
- 1.7 Substitution of components may impair hazardous location safety.
- 1.8 Mounting screw torque shall not exceed 8 lb-in (0.9 Nm)

#### **Panel Mounting**




#### 2.0 FM INSTALLATION WIRING DIAGRAM USING SINGLE OR DUAL CHANNEL INTRINSIC SAFETY BARRIER

#### **Application Notes:**

- **2.1**  $U_i > U_o$  of single channel barrier or  $V_i$  of dual channel barrier
- 2.2  $l_1 > l_2$  of single channel barrier or  $l_1$  of dual channel barrier
- 2.3  $P_i > P_o$  of single channel barrier or  $P_i$  of dual channel barrier
- **2.4**  $L_{i}$  plus interconnecting wiring  $< L_{o}$  of single or dual channel barrier
- **2.5**  $C_i$  plus interconnecting wiring  $< C_o$  of single or dual channel barrier
- 2.6 It is not necessary to use intrinsic safety barriers when installing the PD688/PD689 in Class I, II, III, Division 2, Groups ABCDFG, maximum input voltage = 30 VDC. Division 2 wiring methods must be used when not powering from a barrier.

#### With Backlight



FM Entity Approved transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing. PD688 & PD689 Entity Parameters:

U<sub>i</sub>: 30 V; I<sub>i</sub>: 175 mA; C<sub>i</sub>: 0; L<sub>i</sub>: 0; P<sub>i</sub>: 1.0 W

**HAZARDOUS AREA** 

#### Without Backlight

# Class I, Div 1, 2, Groups ABCD Class II, Div 1, Groups EFG Class II, Div 2, Groups FG Class II, Div 1, 2 Class II, Div 1, 2 Class I, Zone 0, Group IIC S+S-B+BLoop Input FM Entity Approved positive polarity single or dual-channel intrinsic safety barrier used in an approved configuration.

**NON-HAZARDOUS AREA** 

FM Entity Approved transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing PD688 & PD689 Entity Parameters:

U:30 V; I<sub>i</sub>:175 mA; C<sub>i</sub>:0; L<sub>i</sub>:0; P<sub>i</sub>:1.0 W

#### **Open Collector Output**

# Class I, Div 1, 2, Groups FG Class II, Div 1, 2 Class II, Div 2, Groups FG Class III, Div 1, 2 Class III, Div 2, Groups FG Cla



## PD688 & PD689 FM APPROVED, CSA CERTIFIED, & ATEX CERTIFIED Intrinsic Loop-powered Meter Safety Barrier Connections

### 3.0 CSA INSTALLATION WIRING DIAGRAM USING SINGLE OR DUAL CHANNEL INTRINSIC SAFETY BARRIER-ENTITY INSTALLATION

#### **Application Notes:**

**3.1** Barrier parameters must meet the following requirements:


$$\begin{split} & V_{_{\text{oc}}} \text{ or } U_{_{0}} \leq V_{_{\text{max}}} \text{ or } U_{_{i}} \\ & I_{_{\text{sc}}} \text{ or } I_{_{0}} \leq I_{_{\text{max}}} \text{ or } I_{_{i}} C_{_{a}} \text{ or } C_{_{0}} \triangleright C_{_{i}} + C_{_{\text{cable}}} \\ & L_{_{a}} \text{ or } L_{_{0}} \triangleright L_{_{i}} + L_{_{\text{cable}}} P_{_{0}} < P_{_{i}} \end{split}$$

- 3.2 For CSA Certification, barrier and transmitter must be CSA Certified with Entity Parameters and must be connected per manufacturer's instructions.
- 3.3 Class II & III environments require the installation of the meter into one of the following Precision Digital enclosures: PDA2407, PDA2408, PDA2409, or PDA2410.
- 3.4 It is not necessary to use intrinsic safety barriers when installing the PD688/PD689 in Class I, II, III, Division 2, Groups ABCDFG, maximum input voltage = 30 VDC. Division 2 wiring methods must be used when not powering from a barrier.

#### With Backlight



#### NON-HAZARDOUS AREA




CSA Entity Certified transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing.

PD688 & PD689 Entity Parameters:  $V_{max} \colon 30 \text{ V}; \quad I_{max} \colon 175 \text{ mA}; \quad C_i \colon 0; \quad L_i \colon 0; \quad P_i \colon 1.0 \text{ W}$ 

#### Without Backlight



#### NON-HAZARDOUS AREA




CSA Entity Certified transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing PD688 & PD689 Entity Parameters:

 $V_{max} \colon 30 \; V; \quad I_{max} \colon 175 \; mA; \quad C_i \colon 0; \quad L_i \colon 0; \quad P_i \colon 1.0 \; W$ 

#### Open Collector Output

#### HAZARDOUS AREA

#### NON-HAZARDOUS AREA



CSA Entity Certified device installed per manufacturer's Hazardous Location Installation Drawing. PD688 & PD689 Entity Parameters:

 ${\rm V_{max}\colon 30\ V;\ \ I_{max}\colon 175\ mA;\ \ C_{\rm i}\colon 0;\ \ L_{\rm i}\colon 0;\ \ P_{\rm i}\colon 1.0\ W}$ 

#### 4.0 ATEX INSTALLATION WIRING DIAGRAM USING SINGLE OR DUAL CHANNEL INTRINSIC SAFETY BARRIER


#### **Application Notes:**

**4.1** Entity parameters must meet the following requirements:

 $V_{max}$ : 30 V  $I_{max}$ : 175 mA  $C_i$ : 0  $I_{i:0}$ 

4.2 For ATEX Certification, barrier and transmitter must be ATEX Certified with Entity Parameters and must be connected per manufacturer's instructions.


#### With Backlight



ATEX Entity Certified transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing. PD688 & PD689 Entity Parameters:

V<sub>max</sub>: 30 V; I<sub>max</sub>: 175 mA; C<sub>i</sub>: 0; L<sub>i</sub>: 0; P<sub>i</sub>: 1.0 W

#### Without Backlight




ATEX Entity Certified transmitter installed per transmitter manufacturer's Hazardous Location Installation Drawing.

PD688 & PD689 Entity Parameters:

V<sub>max</sub>: 30 V; I<sub>max</sub>: 175 mA; C<sub>i</sub>: 0; L<sub>i</sub>: 0; P<sub>i</sub>: 1.0 W

#### **Open Collector Output**



 $V_{max}$ : 30 V;  $I_{max}$ : 175 mA;  $C_i$ : 0;  $L_i$ : 0;  $P_i$ : 1.0 W

PRECISION DIGITAL +